



INSTALLATION INSTRUCTIONS:

1. Dig footing at proper location 24" wide x 50" deep.
2. Place base post into footing and support in a plumb condition with the outside edge of the pipe tangent to the outside of the foul line. Rotate the post so that the panels are to the inside of the field.
3. Repeat for other foul line.
4. After concrete has cured 48 hrs. place top sections on the bases and lock down with set screws.

PART NO. & DESCRIPTION
551-528 20' Foul Pole W/Wing

SportsPlay Equipment, Inc.

5642 Natural Bridge
St. Louis, MO 63120
(314) 389-4140



By: Candy | Date: 03-19-07 | Scale: 1:25