

The [Baseball Backstop](#) instructions displayed are general and not specific to each unit. A detailed set of instructions is available from [AAA State of Play](#) customer service upon request and will come with your purchase of [Baseball Equipment](#).

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	553-602	2-3/8" O.D. Galv. Pipe	2
2	553-351	Panels	2
3	555-512	1" x 2-3/8" Saddle Clamps	8
4	555-511	1" x 1" Saddle Clamps	4
5	105-017	2-3/8" Pipe Plug	2
6	126-505	5/16" x 1-1/4" Carriage Bolts	16
7	116-504	5/16" x 1" Hex Bolts	4
8	326-501	5/16" Lock Washers	20
9	216-501	5/16" Hex Nuts	20

### GENERAL ASSEMBLY INSTRUCTIONS

- Check each Peice Carefully and Remove any Sharp Projections that may been caused by shipping.
- Do NO Tighten nuts more than hand tight until Entire Assembly is Complete.
- All Threaded Ends of bolts protruding Beyond Nuts should be Cut Off and Peened over to remove any Sharp Edge.

### SPECIFIC ASSEMBLY INSTRUCTIONS

- Layout and dig holes.
- Assemble backstop on the ground with bottom of upright posts at front edge fo holes. Tighten all bolts securely.
- Raise and lower assembly into holes.
- Pour footings. Approximate concrete required-4 cu. ft. (6 sacks of Pre-Mix).

### MAINTENANCE:

Check periodically for loose bolts, broken parts and replace immediately.

